macOS driver installation and use steps

1. Unzip the package and double-click to open the installation package.



2. Installation steps as follows:




Install F8xPrinterDriverForMac
Select a Destination
Introduction
Destination Select
Installation Type
Installation
Summary
Select the disk where you want to install the F8xPrinterDriverForMac software.
Macintosh HD
6.39 GB available
499.96 GB total
iOS 17.0...Simulator
823 MB available
8.93 GB total
Installing this software requires 243 KB of space.
You have chosen to install this software on the disk "Macintosh HD".
Go Back
Continue


Install F8xPrinterDriverForMac
Standard Install on "Macintosh HD"
Introduction
Destination Select
Installation Type
Installation
Summary
This will take 243 KB of space on your computer.
Click Install to perform a standard installation of this software on the disk "Macintosh HD".
Change Install Location...
Customize
Go Back
Install


Install F8xPrinterDriverForMac
The installation was completed successfully.
Introduction
Destination Select
Installation Type
Installation
Summary
The installation was successful.
The software was installed.
Go Back
Close

3. Open "System Settings" and select "Printers & Scanners".



4. Start the printer, load the paper, make the printer in the ready state, and connect the computer with the USB cable.

5. The computer will automatically recognize the printer.



6. How to use: Open the document or image, click "File" → "Print... "



7. Select the printer and set the paper size



8. Open "Printer Options" and set "Print Speed", "Darkness" and other parameters as shown below.





Confirm and click"Print".